





Schaltbild

UFD 245

935 00 215



14. L-E600 Schematic Diagram




Notes:



- indicates positive B power supply.
- indicates signal path.

The tonearm START/STOP and UP/DOWN input signals are represented by arrows.

- When replacing the parts in the darkened area □ and those marked with △, be sure to use the designated parts to ensure safety.
- This is the standard circuit diagram.


The design and contents are subject to change without notice.




E**F**

/STANDBY


J / C (for USA/Canada)




P / U (for Pacex / Other areas)




A (for Australia)



BS (for UK)



E / G (for Europe / Germany)

**1****2****3****4****E****F**